HUFFY® SPORTS

A DIVISION OF RUSSELL CORPORATION

Youth Basketball System Owner's Manual



Toll-Free Customer Service Number for U.S.: 1-800-558-5234
http://www.huffysports.com

PARTS LIST

STOP! **Questions or Missing Parts?**

DON'T go back to store!

Call TOLL-FREE Customer Service Number listed on the front page!

Item	*Qty.*	*Part No.*	*Description*
1	1	900265	Top Pole Section
2	1	900266	Middle Pole Section
3	1	900267	Bottom Pole Section
4	2	900268	Leg, High Holes
5	2	900270	Leg, Low Holes
6	2	201358	Screw, Self Tapping, 6-18, .50 Long
7	4	201362	Cap, Pole, Plastic, Male
8	4	201363	Cap, Pole, Plastic, Female
9	20	201364	Washer, Flat, .25 I.D., .50 O.D.
10	2	203092	Bolt, Hex, 1/4-20 x 1.75" Long
11	4	204591	Bolt, Hex, 1/4-20 x 1.125" Long
12	4	206723	Bolt, Hex, 1/4-20 x 3.625" Long
13	10	203493	Locknut, Nylon Insert, 1/4-20
14	2	201360	Bracket, Board Mounting
15	1	908175	Plate, Mounting
16	1		Net
17	1		Rim
18	2	204589	Wrench
19	1	204590	Screwdriver, Phillips

* YOU MAY HAVE EXTRA PARTS WITH THIS MODEL.

Write Model Number From Box Here:

⚠ WARNING!

READ AND UNDERSTAND OPERATOR'S MANUAL BEFORE USING THIS UNIT.

FAILURE TO FOLLOW OPERATING INSTRUCTIONS COULD RESULT IN INJURY OR DAMAGE TO PROPERTY.

© COPYRIGHT 2005 by HUFFY SPORTS

10/05 ID# P/N 21174**01**

1.

Correctly identify the pole sections. Line up holes as shown and tap together.

NOTE: Make sure holes remain lined up. Secure poles as shown.



2.

Attach legs to pole assembly using bolts (8) and nuts (13). Attach rim and board bracket to backboard using bolts (11) and nuts (20).



⚠WARNING

TOP OF ALL LEGS MUST LINE UP, OR IT MAY TIP OVER.

NOTE:

Do not completely tighten bolt (11) and nut (20) until step 3 is completed

NOTE:

Hole pattern on legs (4) & (5) are different. Use correct legs.



3.

Slide backboard assembly over top pole as shown *fully tightening* bolts (11) and nuts (20). Secure board by inserting screws (6) as shown.





POSITION OF BACKBOARD

Install net (16) to rim (17) as shown.